

HOW TO USE TEMPNFC BUTTONS AND LEDS

There are two buttons: START and INFO

There are two LEDs: Green and Red

Pressing INFO for at least 3 seconds will give the following LED behaviour:

- a) Green and Red for 3 seconds: MEMORY FULL
- b) Red flashing 3 times (700ms ON, 300ms OFF):
 - 1) NO DATA RECORDED
 - 2) ACQUISITION STOPPED
 - 3) WAITING FOR MANUAL START
- c) Green for 3 seconds: MISSION OK
- d) Red for 3 seconds: MISSION FAILED (temperature out of limits, mission duration exceeded limit)

Pressing START for at least 4 seconds will start the logger and Eds will behave as following:

- a) Red for 3 seconds: DEVICE CANNOT BE STARTED
 - 1) MANUAL START NOT ENABLED
 - 2) AVAILABLE MISSIONS EXCEEDED (only for Single Use model) OR EXPIRY CALIBRATION DATE EXCEEDED (only for TempNFC Calib model)
- b) Green for 3 seconds: logger started correctly

When turning on the device (new battery or reset), Green and Red LEDs turn on and the memory is wiped out and default configuration is restored (calibration is not lost). While erasing the memory, the Red LED flashes.