

DISKINTERFACE HS INSTRUCTIONS

How to place different loggers models on the DiskInterface HS


PASTEURDISK
STERILDISK



PASTEURDISK PROBE
STERILDISK PROBE
PASTEURDISK CAN
STERILDISK CAN



PASTEURDISK JUMBO
STERILDISK JUMBO




PASTEURCYL RADIO
STERILCYL RADIO




PASTEURCYL JUMBO
STERILCYL JUMBO




PRESSUREDISK
PRESSUREDISK 05



P-MICRO
S-MICRO



P-MICRO L
S-MICRO L



P-MICRO XL
S-MICRO XL

